



| Lx nr: | Brukes til: | SWL (jevnt fordelt): | Salslys | DMX | Hva |
|--------|-----------------------|----------------------|---------|-----|---------------------|
| LX 1 | Lys - Front | 320 kg. | | 501 | Spotter hovedsal |
| LX 2 | Lys - Front | 320kg. | | 502 | Spotter Galleri |
| LX 16 | Projektor | 100kg | | 503 | Lysrør Galleri |
| LX 3 | Lys | 500kg. | | 504 | Trappelys hovedsal |
| LX 4 | (motor nr. 2 til LX3) | | | 505 | Vegglys hovedsal |
| LX 5 | Kappe | 320Kg | | 506 | |
| LX 17 | Lys | 500kg. | | 507 | |
| LX 6 | Lys | 500kg. | | 508 | LEDslynge tak RED |
| LX 7 | Bein (ledig) | 320kg | | 509 | LEDslynge tak GREEN |
| LX 8 | Teppeskinne | 320kg. | | 510 | LEDslynge tak BLUE |
| LX 9 | Kappe | 320kg | | 511 | LEDslynge tak WHITE |
| LX 10 | Lys | 500kg. | | | |
| LX 11 | Bein, Lys | 320kg. | | | |
| LX 12 | Lys | 500kg. | | | |
| LX 13 | Kappe/Horrisontlys | 320kg. | | | |
| LX 14 | Bakteppe på skinne | 320kg. | | | |
| LX 15 | Teppeskinne/Backdrop | 320kg. | | | |